

1                   **(January 3, 2006)**

2                   **Transverse Joints**

3                   The full depth end of each lane of planing shall be squared off to form a uniform  
4                   transverse joint. The Contractor shall construct and maintain a temporary HMA  
5                   wedge in accordance with Section 5-04.3(12)A across the entire width of the  
6                   transverse edge when traffic is allowed on the planed surface prior to paving. The  
7                   wedge shall be constructed before opening the lane to traffic. The Contractor shall  
8                   remove the wedge immediately prior to paving.